


## Personal Hygiene Appliance

*ROSE Bidet*



**Elongated : ALB-570E**

**Round Front : ALB-570R**

## Contents

Important Safeguards .....	2
Grounding Instructions .....	4
Parts Identification .....	5
Basic Instructions .....	8
Functions & Operation .....	9
Installation .....	13
Trial Operation .....	16
Detachment .....	17
Maintenance .....	18
Water Tank Drainage .....	19
Trouble Shooting .....	20
Product Specifications .....	40
Product Registration .....	40

- This product was manufactured for household use only
- Read all operating instructions before installation and use
- Please save this operating instruction manual and place in an easily accessible location

# Important Safeguards

READ ALL INSTRUCTIONS BEFORE USING.

## **DANGER** To reduce the risk of electrocution.

- Do not use while bathing.
- Do not place or store product where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not reach for a product that has fallen into water. Unplug immediately.

## **WARNING** To reduce the risk of burns, electrocution, fire or injury to persons.

- Close supervision is necessary when this product is used by, on, or near children or invalids.
- Use this product only for its intended use as described in this manual. Do not use any attachments unless recommended by the manufacturer.
- Never operate this product if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the product to a service center for examination and repair.
- Keep the cord away from heated surfaces.
- Never block the air openings of the product or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
- Never use while sleeping or drowsy.
- Never drop or insert any object into any opening or hose.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Connect this product to a properly grounded outlet only. See Grounding Instructions.
- Any other servicing should be performed by an authorized service representative.
- Do not dismantle, repair, or alter the unit.
- Do not pour or spray water on to the unit.
- The unit must be grounded.
- Do not touch the power plug with wet hands.
- Properly connect the power cord to the electrical outlet corresponding to the rated voltage of the unit.
- Do not use damaged or loose power cord.

# Important Safeguards

**WARNING** To reduce the risk of burns, electrocution, fire or injury to persons.

- **Keep the unit away from fires or inflammable substance.**
- **Do not connect to the industrial water supplies.**
- **Do not connect other electrical appliances to the same power socket connected to the unit.**
- **Replace damaged power cord and plug by authorized service center.**
- **Caution against low temperature burns.**
- **Before removing the unit from the toilet bowl, disconnect the power plug first.**

**CAUTION** To reduce the risk of injury to persons or damage to the product or the property.

- **Do not place heavy objects or step on the unit.**  
It may cause product damage or injury.
- **When cleaning the unit, do not use any chemicals. Clean the unit with moist, well-wrung soft cloth. For excessive stains, use soft cloth moistened with mild dish-wash detergent and wipe out with dry cloth.**  
It may cause product damage.
- **Do not slam down the lid.**  
It may cause product defect.
- **Do not lean on the lid.**  
It may cause product defect.
- **When not in use for a long period of time, disconnect the power plug and drain the water tank.**  
Tank water may be contaminated and cause skin troubles.
- **Do not twist or pull the connection hoses.**  
It may affect water supply or cause water leakage.
- **Do not cover up the warm air outlet or insert hands or other objects.**  
It may cause burn or electric shock.
- **Do not operate the unit during product malfunction.**  
Disconnect the power and call the authorized service center.  
It may cause fire or electric shock if the unit is operated while it is out of order.

**SAVE THESE INSTRUCTIONS**

# Grounding Instructions




## Grounding Instructions

- This product should be grounded. In the event of an electrical short circuit, grounding reduce the risk of electric shock by providing an escape wire for the electric current. This product is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.

**DANGER -** Improper use of the grounding plug can result in a risk of electric shock.


If repair or replacement of the cord or plug is necessary, do not connect the grounding wire to either flat blade terminal. The wire with insulation having an outer surface that is green with or without yellow stripes is the grounding wire. Check with a qualified electrician or serviceman if the grounding instructions are not completely understood, or if in doubt as to whether the product is properly grounded.

- This product is for use on a nominal 120V circuit and has a grounding plug that looks like the plug illustrated in sketch A in Figure 1. A temporary adapter, which looks like the adapter illustrated in sketches B and C, may be used to connect this plug to a 2-pole receptacle as shown in sketch B if a properly grounded outlet is no available. The temporary adapter should be used only until a properly grounded outlet (sketch A) can be installed by a qualified electrician. The green colored rigid ear, lug and the like extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used, it must be held in place by the screw.
- If it is necessary to use an extension cord, use only a three wire extension cord that has a three-blade grounding plug, and a three-slot receptacle that will accept the plug on the product. Replace or repair a damaged cord.




# Parts Identification

## 1 Main unit



# Parts Identification

## 2 Accessory Parts




Fixation Bolts



Rubber Packings




Washers




Fixation Nuts




PVC Flexible Hose(for Main Unit)




T-Valve



Deodorization



Conversion NUT  
(1/2" to 3/8")



Conversion NUT  
(3/8" to 1/2")


# Parts Identification

## 3 Control Panel




# Basic instructions

## 1 Sit on the seat




- When seated, the "WATER" indication lights up.
- Deodorization automatically starts.

## 2 Press the "CLEANSING" or "BIDET" button




- Operate either the "CLEANSING" or the "BIDET" function.
- Each function operates for 1 minute.
- Move cleansing runs by pressing "CLEANSING" or "BIDET" button while using.

## 3 Press the "DRY" button



- The "DRY" indication lights up and warm air dryer starts.
- Dryer function will operate for 3 minutes.  
(Running for 1 minute in auto-clean mode)
- Drying operation can be maximized by gently wiping wet area with toilet paper.

## 4 Press the "STOP" button



- Stops all operating functions.

- When using the unit, please sit in center.  
(The seat sensor may not be properly activated, if not seated in center. Please refer to 'seat sensor' on 12 page.)
- If the "CLEANSING" or "BIDET" function is operated for a long time, water temperature will drop gradually. To regain warm water, resume operation after 3 minutes.

# Functions & Operation

## ● Move (Oscillating Wash)

- Move cleansing runs by pressing "CLEANSING" or "BIDET" button while cleansing or bidet cleansing.
- Nozzle stops by pressing "CLEANSING" or "BIDET" button again.

## ● Water Pressure Adjustment

- The water pressure level indication lights up when the seat is occupied. The unit remembers the last water pressure settings.
- Water pressure can be adjusted by pressing the "HI" or "LO" button.
- When the seat is unoccupied, the indication of water pressure level goes out.

## ● Nozzle Position Adjustment

- Press the "FR" or "BK" button to adjust the nozzle position during "CLEANSING" or "BIDET" function.
- The unit remembers the last nozzle position settings.

## ● Water Temperature Adjustment

- Press the "WATER" button to adjust the water temperature level.  
Select the desired level.

## ● Warm Seat Temperature Adjustment

- Press the "SEAT" button to adjust the seat temperature.  
Select the desired level.

※ The unit remembers the water and seat temperature settings even if the power is shut off.  
No need to readjust the temperature settings after a power failure.

# Functions & Operation

## Warm Air Dryer Temperature Adjustment

- During the dryer operation, the "WATER/DRY" LED indicates the temperature level of the warm air dryer.
- The unit remembers last warm air temperature settings.  
Press "HI" or "LO" button to adjust the temperature of the warm air.

## Luminous LED

- Luminous LED activates by pressing "LIGHT" button and luminous function runs automatically when getting dark. To cancel the luminous function, press "LIGHT" button again and LED goes OFF.
- When luminous function runs, Bidet senses automatically toilet light and luminous LED goes on. User can use conveniently bidet without toilet light.
- Electric power consumption is minimal so use the luminous function without worries about the electric bill.

## Auto Power Saving

- Locate the LED indication at "AUTO" position by pressing "POWER SAVING" button.
- It maintains 30 °C(86 °F) for warm water and seat temperature each in the auto power saving mode.
- Power saving function is temporarily released, when sitting on the seat.  
Power saving function runs again, when moving away from the seat.
- To cancel power saving function, press "POWER SAVING" button twice, then LED indication goes OFF.

## Super Power Saving

- Locate the LED indication at "SUPER" position by pressing "POWER SAVING" button.
- Bidet senses toilet luminosity for itself and shows excellent power saving efficiency in the super power saving mode.
- Water and seat temperature maintain normal temperature in the super power saving function and power saving mode is temporarily released when toilet lightning goes ON.
- It returns to normal mode from power saving mode even if occupying the seat in dark condition.
- To cancel super power save, press "POWER SAVING" button, then LED goes OFF.

# Functions & Operation

## Deodorization

- Deodorizing function automatically runs when occupying the seat. Sound of deodorization running appears.
- When moving away from the seat, deodorizing function runs for 1 minute more and stops automatically. (When occupying the seat for over 30 minutes, it runs for 30 minutes and stops)
- For fragrant function, put the aromatic instead of deodorizing filter. Need to purchase from specialty store.

## Self Nozzle Cleaning

- Before and after each operation, the self nozzle cleaning function runs and sanitizes the nozzle head.

## Nozzle Cleaning

- Press the "CLEANSING" and "BIDET" button simultaneously. The nozzle comes out.
- Clean the nozzle manually with a small brush. Press the "STOP" button and the nozzle returns to its storage position, then self-cleaning function is operated.

## Power On/Off

- Press the "STOP" button for more than 4 seconds and then the power indication light goes off. Unit will be power off completely.
- Press any button to start the power on.
- The unit remembers all of the prior settings in spite of an electrical outage so no need to reset functions after power is back.

# Functions & Operation

## Help

- Buzzer sounds for 30 seconds to call guardian if pressing "HELP" button.
- Buzzer sound stops by pressing "STOP" button or "HELP" button again during help function is running.

## Burn protecting system at the low temperature

- Seat temperature goes down in case the temperature position is "HI" when sitting on the seat for over 30 minutes. (May cause burns at the low temperature in case sitting on the seat for a long time.)
- It returns to set point when resetting or moving away from the seat.

## Auto Cleansing

- Move cleansing and warm air dryer run for 1 minute each by pressing "AUTO CLEAN" button.
- The 3rd level for water pressure , the 2nd level for warm air dryer temperature and the 3rd level of nozzle position are automatically set-up. (Water pressure, warm air dryer temperature and nozzle position can be adjusted according to user preference)
- When using auto clean function, Sensor forces to set the water & seat temperature to "Medium", in case the temperature were set up on the "High" position.  
(Can adjust the water & seat temperature according to user preference)
- Can return to previous auto-clean function that was set up when canceling auto-clean function or pressing stop button.
- Useful function for the old, the weak, and children.

## Seat Sensor

- To improve sensor efficiency, two(2) seat sensors are installed in both the unit and the seat both.  
(Refer to page 5)
- Two seat sensors locations
  - ① Rear seat sensor : Activating when weight is felt in back of seat.
  - ② Front seat sensor : Activating when skin contacts the seat.**Therefore, Seat sensors may not be activated if cloth cover or other materials are placed on the seat.**

# Installation




## Caution before installation!


- Check whether the size and shape of the toilet seat are suitable for installation.
- Check all the accessory parts are in place.
- Do not connect the power until installation is finalized.
- Ground connection should be done by authorized service personnel only.

## 1 Remove the existing toilet seat.

- Remove the existing toilet seat and lid by unfastening fixation nuts underneath.
- Keep the detached seat, lid and nuts for later use.




## 2 Drain toilet water tank completely after turning off the water supply by turning the shut off valve clockwise.



# Installation


## 3 Detach the water supply pipe on the part of the shut off valve, then install the T-valve.

- T-valve included is standard 1/2" size.  
In case connecting the T-valve to the 3/8" water supply line, use the conversion nut. (Refer to right Fig.)
- In case of a rigid pipe, T-valve cannot be installed.  
Needs to purchase and install the separate flexible hose(for water tank).




## 4 Insert the fixation bolts into the grooves underneath the unit according to the distance of the fixation holes of the toilet.

- There are two kinds of possible distance to install, one is 140mm and the other is 155mm.
- Out side grooves is for 155mm and inside grooves is for 140mm.




# Installation


- 5** Insert the bolts into the holes on the toilet seat and fasten the nuts after fixing the rubber packings and washers.



- 6** Connect the PVC flexible hose(for Main Unit) to the T-valve and water supply inlet.




- 7** Insert the deodorization cartridge into the unit.



# Trial Operation

- 1 Open the shut off valve by turning counterclockwise.
- 2 Check for any water leakage on the connection hoses.



- 3 Connect the power plug.


- If the power indication light is not turned on after the power plug connection, press any button, then power goes ON.

★ **WARNING**

Do not turn over or move the unit after power connection.  
It may cause electric shock.

- 4 Press the "CLEANSING" or "BIDET" button to fill up the water tank. One long beep will sound when tank is full.


- 5 To test the water spray operation, press either "CLEANSING" or "BIDET" button. Cover the nozzle with hand to prevent water from spritzing.



# Detachment

Follow the below instructions if in need to detach the unit to move.

- 1 Disconnect the power plug.
- 2 Close the water supply by turning the shut off valve clockwise and drain the toilet water tank completely.
- 3 Disconnect the PVC flexible hose from the unit and unfix the unit from the toilet seat.
- 4 Unfasten the drain plug underneath the unit and drain the water completely in the water tank.




- 5 Disconnect the T-valve, Conversion nuts, PVC flexible hose.
- 6 Connect the water-supply hose to the shut off valve.
- 7 Open the shut off valve by turning anticlockwise and check any leakages on the connections.
- 8 Reinstall the original seat and lid to the toilet seat.

# Maintenance

## Cleaning the Water Strainer

- 1 Close the water supply by turning the shut off valve clockwise and drain the toilet water tank completely.
- 2 Remove the water strainer by turning counterclockwise.
- 3 After cleaning the strainer, reinsert it by turning clockwise.
- 4 Open the shut off valve.



## Cleaning the Nozzle

- 1 Press the "CLEANSING" and "BIDET" button simultaneously. The nozzle comes out and stops.
- 2 Clean the nozzle manually with a small brush. To return the nozzle to its storage position, press the "STOP" button. Then nozzle self cleaning function is automatically activated.




## External Cleaning

- The external case of the unit is made of the plastic which may be damaged by scrubbers, chemicals, etc. Do not use any chemicals.
- Clean the unit with a tightly wrung wet soft cloth. Do not spray water the unit.
- Disconnect the power plug when cleaning. Please be careful not to splash the water to the plug or socket.
- Touching the power socket with wet hands can cause an electric shock.




# Water Tank Drainage

- 1 Disconnect the power plug first.
- 2 Close the shut off valve by turning clockwise.




- 3 After placing a basin (4ℓ) under the drain hose, unfasten the drain plug and drain the water tank completely.



## Freeze Prevention during Winter

- 1 Connect the power cord and check if the unit power is on.
- 2 Do not turn off the "WATER" level and adjust water temperature to "LO" or higher.
- 3 If not in use for a long time, drain the water tank.



# Trouble Shooting

Check the followings details before call for service.

Problem Description	Possible Causes
<b>Unit does not operate at all</b>	<ul style="list-style-type: none"><li>• The power is OFF condition.</li><li>☞ Press any button to check.</li><li>• The power plug is not connected.</li><li>• There is a power failure.</li></ul>
<b>No water spray</b>	<ul style="list-style-type: none"><li>• The shut off valve is closed.</li><li>• There is water supply outage.</li></ul>
<b>Low water pressure</b>	<ul style="list-style-type: none"><li>• The water pressure level is set to "LO".</li><li>• The water strainer is clogged.</li></ul>
<b>Water temperature is low</b>	<ul style="list-style-type: none"><li>• The water temperature level is turned off or set to "LO".</li><li>• Warm water can be used for about 40 seconds at the "MID" setting. It will take about 3 minutes to regain selected temperature.</li></ul>
<b>Seat is not warm</b>	<ul style="list-style-type: none"><li>• The warm seat temperature level is turned off or set to "LO".</li></ul>
<b>Dryer air is not warm</b>	<ul style="list-style-type: none"><li>• The warm air dryer temperature level is turned off or set to "LO".</li></ul>
<b>Buzzer sound happens</b>	<ul style="list-style-type: none"><li>• The help function is running.</li></ul>



# Product Specifications

Item		ALB-570E	ALB-570R
Power Supply		AC 120V 60Hz	
Max. Power Consumption		660W	
Length of Power Cord		3,94ft (1,2m)	
Water Supply Connection		Direct connection to the water supply	
Water Supply Pressure		14.223psi~106.675psi (1.0kgf/cm <sup>2</sup> ~ 7.5kgf/cm <sup>2</sup> )	
Cleansing	Water Flow Rate	Cleansing	Max. 0.291gal/min (1.1 l /min)
		Bidet	Max. 0.343gal/min (1.3 l /min)
	Water Pressure Adjustment	5 Levels	
	Temp. Adjustment	Normal Temp., 93.2°F(34°C), 98.6°F(37°C), 104°F(40°C)	
	Heater Capacity	600 W	
	Safety Device	Thermal Fuse, Thermostat, Water Level Sensor	
Warm seat	Temp. Adjustment	Normal Temp., 95°F(35°C), 100.4°F(38°C), 105.8°F(41°C)	
	Heater Capacity	55W	
	Safety Device	Thermostat	
Dry	Temp. Adjustment	Normal Temp. ~ 122°F(50°C), (5 Levels)	
	Heater Capacity	150W	
	Safety Device	Thermal Fuse, Bi-metal	
Deodorization		Catalytic Deodorization	
Water Supply Temp.		37.4 °F (3 °C) ~ 95 °F (35 °C)	
Temp. of circumstance for use		37.4 °F (3 °C) ~ 104 °F (40 °C)	
Product size		1.55ft(W) x 1.74ft(L) x 0.54ft(H) [470mm(W) x 530mm(L) x 165mm(H)]	1.55ft(W) x 1.62ft(L) x 0.54ft(H) [470mm(W) x 495mm(L) x 165mm(H)]
Product weight		10.6lbs (4.8kgs)	10.4lbs (4.7kgs)

# Product Registration

For other issues or questions, contact Customer Service :

## Contact Information

Aqua Life Water Systems, Inc.  
1369 W. Washington Blvd  
Los Angeles, CA 90007

Phone : 1-800-222-5502

E-Mail : [customer@aqualifewater.com](mailto:customer@aqualifewater.com)

Web : [www.aqualifewater.com](http://www.aqualifewater.com)

## Warranty

Rose Bidet is covered by one year factory warranty, valid from the original date of purchase.

To receive important product updates, Please complete & return enclosed registration card, or register your products at <http://www.aqualifewater.com>